



Audio Panel Basic Setting Procedures

Cessna N4601G



1. When the “Starting Engine” checklist directs you to Check/Set Audio, the above picture shows you what to look for and the switch settings to check for basic Radio #1 Transmit and Receive capabilities. At Jack Edwards Airport it’s 122.7 CTAF.
2. The RED BOX area is the only portion of the Audio Panel that you need to become familiar with for your private pilot training. The picture shows the correct AUDIO panel setting to transmit and receive on 122.7. The XMTR switch (which means transmit radio) is set on 1 and the AUTO switch is set on PHONE (headphones).
3. When you are ready to listen to the AWOS at KJKA press the transfer button on Radio #1 to move 134.525 over to the “use” position and leave the audio panel set as is.
4. After receiving the AWOS information return your Radio #1 to 122.7 CTAF.

Later in your training you will be instructed on the use of Radio #2 and the AUDIO panel settings for “Dual Com” operations.